

MELA MUTET™ MELAMINE FOAM WAVE BAFFLES

HANGING INSTALLATION INSTRUCTIONS

RECEIVING AND HANDLING

Prior to unpacking, check package for any obvious shipping damage. If no evidence of damage is present, move package to a dry/controlled area and inspect it for any lesser-noticeable damage. If damage has been identified, record it/photograph it, and open to inspect for concealed damage. Wear gloves when handling the foam, and handle with care at all times to avoid damage to the material. Do not twist or bow the foam during installation.

INSTALLATION TOOLS

- Corkscrew hangers (provided)
- Light duty cable or chains
- Cable clamps
- Level

HOW TO INSTALL

- 1 Choose which edge you will mount on (for portrait or landscape orientation). Measure out at least 3" in from the edge of the baffle and center along the thickness of the baffle. Mark that point. Repeat on the other edge.
- 2 Using the provided corkscrew hanger, screw into the foam until only the eyelet is visible. Apply light downward pressure as you screw in the corkscrew. Do not poke into the foam. Eyelet should be parallel with the edge of the baffle.
- 3 Repeat steps on the other edge of the baffle.
- 4 Loop suspension cable (provided by other) into the eyelet on the corkscrew and close the loop with a cable clamp or similar hardware.
- 5 Anchor the suspension cable to the roof deck or ceiling structure. Use level to ensure an even hang.



Wear gloves when handling foam. If the corkscrew is crooked or comes through the side, start with a fresh hole and be sure to match the other edge symmetrically.

(CONTINUED ON NEXT PAGE)

MELA MUTETM MELAMINE FOAM WAVE BAFFLES

HANGING INSTALLATION INSTRUCTIONS

